



Measuring Guide

Waist (At top of waistband)

Measure from one end of the waistband to the other with the garment laid down flat.

Hip (At 15cm below top of waistband)

Measure across the width of the garment at 15cm down from the waistband with the garment laid down flat.

Inside Leg

Measure from the crotch point to the hemline at the inside leg.



APTUS Performance Female Legging
Code: AAAA111888

APTUS Performance Female Legging

To fit (Inches)	18/20"	22/24"	24/26"	26/28"	28/30"	30/32"	34/36"	38/40"	42/44"
Waist (cm)*	25	29	31	33	35	37	41	45	49
Hip (cm)*	29	33	35	37	39	41	44	47	51
Inside Leg	58	61	62	63	64	65	66	67	68

***Please note these are garment measurements - NOT body measurements.**

PLEASE NOTE THAT GARMENT MEASUREMENTS AND SIZE ARE A GUIDELINE TO BRITISH STANDARD SIZING.