



Measuring Guide

Chest (At 2cm from under arm)

Measure across the chest at 2cm below the underarm with the garment laid flat.

Front Length

Measure from the side neck point of the shoulder down to the hemline.

Shoulder & Sleeve Length (Including Cuff)

Measure from the point where the shoulder seam and neck opening meet down to the end of the cuff.



APTUS Performance Female Full Zip Training Top
Code: AAAA111895

APTUS Performance Female Full Zip Training Top

To fit chest (Inches)	20/22"	22/24"	26/28"	30/32"	32/34"	34/36"	38/40"	42/44"	46/48"	50/52"
1/2 Chest (cm)*	34.5	38	43	48	50.5	53	58	63	68	73
Front length (cm)	48	54	58	62	65	68	70	72	74	76
Sleeve length (cm)*	51	64	67	70	72	75	78	81	84	87

***Please note these are garment measurements - NOT body measurements.**

PLEASE NOTE THAT GARMENT MEASUREMENTS AND SIZE ARE A GUIDELINE TO BRITISH STANDARD SIZING.